

Use USB_driver_3_0_2_Installer.exe to install the USB drivers
for Septentrio receiver mosaic-1.
The USB drivers are also installed as part of RxTools.